STANDARD UPRIGHTS UPRIGHT **EXTENSIONS** for Standard Uprights uprights see pg 12

Each Upright is equipped with a set of (4) slots positioned every 90°

 Slots are 	located 3/8" from top
leaving a	solid ring for added
strength	
2111-2-1	

- · 3' Uprights have one set of four slots at the top · 6' and over Uprights have two sets
- of four slots (one set at 3' and one set at the top)
- · Additional sets of four slots may be added at any location
- · Chrome end cap is standard on all 3'
- · All tube surfaces have protective anodized coating
- · Special Order Black Powder Coated available for an additional cost (call for prices)
- · Custom Heights Available







Standard Uprights

1 1/2" O.D. STANDARD UPRIGHTS

6' x 1 1/2" O.D.

8' x 1 1/2" O.D.

10' x 11/2" O.D.

12' x 1 1/2" O.D

2" O.D. STANDARD UPRIGHTS

6' x 2" O.D.

8' x 2" O.D.

8' x 1 1/2" O.D.

OLD STYLE SCREW-IN TYPE

Custom Heights available

2 Piece 8' x 1 1/2" O.D.

Custom Heights available

3' x 2" O.D. (with chrome cap)

3' x 1 1/2" O.D. (with chrome cap)

3' x 1 1/2" O.D. (with chrome cap)

Part #

315

615

815

1015

1215

Special

320

620

820

Special

3155

8155

REPAIR END For Standard Upright see pg 12

2 PIECE

MODELS



2-PC 8' UPRIGHTS

Maximum Tube length 51' Part # 815-2

Special Order

BLACK ANODIZED

ADJUSTABLE

UPRIGHTS AND

BLACK POWDER

COATED BASES

available for an

additional cost (call for prices)

UPRIGHT

EXTENSIONS

for Adjustable

Uprights

see pg 12

UNIQUE SLIP-LOCK FEATURE

- · Easy to set up, accurate and rapid height adjustments
- · Quickly adjusts to any height within the specific model range
- · No tools required for set-up or disassembly
- · No knobs or wing nuts to adjust
- · All tube surfaces have protective anodized coating
- · Longer 2 pc and 3 pc Uprights available

HOW SLIP-LOCK WORKS

The SLIP-LOCK collar assembly locks automatically when the inner pole is raised vertically to the desired height. As a vertical load is applied downward, the ball-taper lock feature locks tighter. The more pressure applied downward the tighter it will lock. To release the lock, simply raise the inner pole slightly and lift the release ring. For SAFETY, hold the inner pole firmly while raising or lowering the height.

2 PC ADJUSTABLE UPRIGHT Size Part # 3' - 5' TS35 TS47 4' - 7 **TS58** 6' - 10' TS610 TS712 7' - 12' TS814 8' - 14' TS916 9' - 16'

TS1018 10' - 18' TS1120 11' - 20' 12' - 22' TS1222 TS1324 13' - 24'


TS1426 14' - 26'

REPAIR **COLLAR KIT** for Adjustable

Upright - see pg 12

REPAIR END for Adjustable Upright see pg 12







3 PIECE

MODELS

. 1-13/16" Tube

3 PC ADJUSTABLE UPRIGHT		
Part #	Size	
TS511	5' - 11'	
TS614	6' - 14'	
TS717	7' - 17	
TS820	8' - 20'	
TS923	9' - 23'	

2" Tube requires 2" diameter pin



for corresponding dollies